

## SELECTION OF °C OR °F OPERATION MODE

Ir33 (green light)

PRESS SET TOGETHER WITH **Prg** <sub>mute</sub> FOR MORE THAN 5 SECONDS;  
THE DISPLAY WILL SHOW THE NUMBER 0 REPRESENTING THE PASSWORD PROMPT;

PRESS **▲** <sub>aux</sub> OR **▼** <sub>def</sub> UNTIL DISPLAYING THE NUMBER 22 (this code allows the access to the parameters);

CONFIRM BY PRESSING SET;

THE DISPLAY WILL SHOW THE FIRST PARAMETER r2;

PRESS **▼** <sub>def</sub> UNTIL DISPLAYING r5;

CONFIRM BY PRESSING SET (FOR ENTER IN THE PARAMETER)

NOTE : /5: Select °C or °F

Defines the measurement unit (degrees Centigrade or degrees Fahrenheit) shown on the display.

/5=0 to work in degrees Centigrade.

/5=1 to work in degrees Fahrenheit.

See pag. 42 manual

0 = °C

1 = °F

PRESS **▲** <sub>aux</sub> OR **▼** <sub>def</sub> TO CHANGE THE VALUE;

CONFIRM BY PRESSING SET;

PRESS **Prg** <sub>mute</sub> FOR MORE THAN 5 SECONDS TO MEMORIZE THE CHANGED PARAMETER.

ON DISPLAY WILL RETURN THE VALUE OF THE FLUID TEMPERATURE.

