

CONTROL DELTA MODIFICATION

Ir33 (green light)

PRESS **SET** TOGETHER WITH ***Prg*** ***mute*** FOR MORE THAN 5 SECONDS;
THE DISPLAY WILL SHOW THE NUMBER **0** REPRESENTING THE PASSWORD PROMPT;

PRESS ***aux*** OR ***def*** UNTIL DISPLAYING THE NUMBER **22** (this code allows the access to the parameters);

CONFIRM BY PRESSING **SET**;

THE DISPLAY WILL SHOW THE FIRST PARAMETER **r2**;

PRESS ***def*** UNTIL DISPLAYING **rd**;

CONFIRM BY PRESSING **SET** (FOR ENTER IN THE PARAMETER)

PRESS ***aux*** OR ***def*** TO CHANGE THE VALUE;

CONFIRM BY PRESSING **SET**;

PRESS ***Prg*** ***mute*** FOR MORE THAN 5 SECONDS TO MEMORIZE THE CHANGED PARAMETER.

ON DISPLAY WILL RETURN THE VALUE OF THE FLUID TEMPERATURE.

